








B - B




Q+(3) Normativa ISO 22241-4:
I requisiti minimi funzionali e
geometrici sono stabiliti in:
- Figura 2: Inlet Adapter
- Tabella 3: Caratteristiche Magnete

FILLER NECK CONNECTION IN ACCORDANCE
WITH DIN 73400, CAM B



Q+(2)
REQUISITI E RACCOMANDAZIONI GENERALI
(ISO 22241-3 Part 3: Handling transportation and storage)
Pulizia delle superfici a contatto con AUS 32
Tutte le superfici a diretto contatto con AUS 32 devono essere prive di corpi estranei (carburante, olio, grasso, detergente, polvere e qualsiasi altra sostanza). Per evitare qualsiasi contaminazione di AUS 32 con oligoelementi, particelle e corpi estranei, le superfici del tappo e/o del filtro devono essere pulite con acqua distillata o deionizzata.
L'uso dell'acqua del rubinetto dovrebbe essere particolarmente evitato a causa delle elevate concentrazioni di alcali e terra alcalina, ioni metallici ivi contenuti. Tuttavia, se l'acqua distillata o l'acqua deionizzata non sono prontamente disponibili, il materiale potrebbe essere pulito con acqua di rubinetto, a condizione che l'ultimo risciacquo venga effettuato utilizzando AUS 32 prima di essere utilizzato.

GENERAL REQUIREMENTS AND RECOMMENDATIONS
(ISO 22241-3 Part 3: Handling transportation and storage)
Cleanliness of surfaces in contact with AUS 32
All surfaces in direct contact with AUS 32 shall be free of foreign matter (fuel, oil, grease, detergent, dust and any other substance).
To avoid any contamination of AUS 32 with trace elements, particles and foreign matter, surfaces of equipment (cap and/or strainer) shall be cleaned with distilled or de-ionized water and AUS 32 in the last cleaning step immediately before the use with the AUS 32 to be handled with the equipment.
The use of tap water should especially be avoided due to the high concentrations of alkali and alkali earth metal ions therein. However, if distilled water or de-ionized water is not readily available, the material may be cleaned with tap water, provided the last rinse is done using the AUS 32 to be handled with the equipment.



00088402